USER'S INFORMATION, MAINTENANCE AND SERVICE MANUAL

HIGH EFFICIENCY TUBULAR HEAT EXCHANGER SERIES

MODELS: PV8*UH/FC8V*UH/FL8V*UH/LC8V*UH/LL8V*UH Two Stage Variable Speed Upflow / Horizontal / Low NOx)

ISO 9001 Certified Quality Management System

TABLE OF CONTENTS

CONTACT INFORMATION 1
USER'S INFORMATION 1
SAFETY 1
CONTACT INFORMATION 1
INSTRUCTIONS FOR EXAMINING THE FURNACE INSTALLATION 2
HOW YOUR GAS FURNACE WORKS 3
START-UP AND SHUTDOWN INSTRUCTIONS 3
Read the Instructions Below Before Trying to Start the Furnace . . 3
Operating Instructions: 3
To Turn Off the Appliance: 3
FURNACE USER MAINTENANCE 4
Air Filters 4
Removing Filters 4
Blower Care 4
Motor Lubrication 4
SERVICE AND MAINTENANCE MANUAL 4
SAFETY SECTION 4
FURNACE MAINTENANCE SECTION 5
FURNACE CLEANING SECTION 5
Burner Removal/Cleaning 5
Cleaning the Heat Exchanger 5
SEQUENCE OF OPERATION 5
CONTROL BOARD 6
HEATING AIRFLOW 6
ADJUSTMENT OF FAN CONTROL SETTINGS 6
Heating Indoor Fan Off Delay 6
Continuous Blower Operation: 7
Delay Tap Selection 7
Humidistat 7
Hot Surface Ignition System 7
TROUBLESHOOTING 7
FURNACE CONTROL DIAGNOSTICS 8
DIAGNOSTIC FAULT CODE STORAGE AND RETRIEVAL 8
REPLACEMENT PARTS LIST 10
WIRING DIAGRAM 13
LIMITED WARRANTY 16

CONTACT INFORMATION

- Go to website at www.york.com click on "contact", then click on "contact form" and follow the instructions.
- Contact us by mail:

York International
Consumer Relations
5005 York Drive
Norman, OK 73069

The manufacturer recommends that the user read all sections of this manual and keep the manual for future reference.

⚠WARNING

FIRE OR EXPLOSION HAZARD - Failure to follow safety warnings exactly could result in serious injury, death, or property damage.

— Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

— WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone (including cell phone) in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

— Installation and service must be performed by a qualified installer, service agency or the gas supplier.

SECTION I: USER'S INFORMATION

SAFETY

1. The furnace area must be kept clear and free of combustible materials, gasoline and other flammable vapors and liquids.
2. Insulating materials may be combustible. The furnace must be kept free and clear of insulating materials. The furnace area must be examined when installed in an attic or other insulated space or when insulation is added to be sure that the insulation material has been kept away from the furnace.
3. The furnace needs air for combustion in order to operate properly and safely. Do not block or obstruct air openings on the furnace, air openings to the area where the furnace is installed, or spaces around the furnace.
4. Follow the instructions exactly as shown on the OPERATING INSTRUCTION LABEL or the Start-up and Shutdown Instructions on Page 3 of this manual when lighting the furnace or turning the furnace off.
5. Should the gas supply fail to shut off or if overheating occurs, shut off the gas valve to the furnace before shutting off the electrical supply.
6. Do not use this furnace if any part has been under water. A flood-damaged furnace is extremely dangerous. Attempts to use the furnace can result in fire or explosion. A qualified service agency should be contacted to inspect the furnace and replace all gas controls, control system parts, electrical parts that have been wet or the furnace if deemed necessary.



FIGURE 1: Component Locations

7. NEVER . . .Store flammable materials of any kind near your furnace. Gasoline, solvents, and other volatile liquids should be stored only in approved containers outside your home. These materials vaporize easily and are extremely dangerous.
8. NEVER . . .Store cleaning materials near your furnace. Materials such as bleaches, detergents, powdered cleansers, etc., can cause corrosion of the heat exchangers.
9. NEVER . . . Use the area around your furnace as a storage area for items which could block the normal flow of air. This flow of air is required for ventilation of the various furnace components.

⚠WARNING

FIRE OR EXPLOSION HAZARD

This furnace is designed and approved for use with Natural Gas and (LP) Propane Gas ONLY. DO NOT BURN ANY LIQUID FUEL OR SOLID FUEL IN THIS FURNACE.

Burning any unapproved fuel will result in damage to the furnace heat exchanger, which could result in Fire, Personal Injury, and/or Property Damage.

INSTRUCTIONS FOR EXAMINING THE FURNACE INSTALLATION

It is the owner's responsibility to ensure that an annual inspection of the entire heating portion of the unit is made by a qualified service agency. Examine the furnace as outlined below in steps "1 - 6" before each heating season. Use Figure 3 for visual reference.

1. Examine the heat exchanger, vent pipe, combustion air passes gas, vent connectors and chimney to be sure they are clear and free of obstructions.
2. Examine the vent pipe making sure it is firmly in place, that it slopes slightly upward and is physically sound without holes and all of the connections are secure.
3. Examine the return-air duct connections to make sure they are physically sound, sealed to the furnace casing, and the ducts terminate outside the space containing the furnace.
4. Examine the furnace casing making sure the physical support is sound without sagging, cracks or gaps. Examine the furnace base making sure it is physically sound without cracks, gaps or sagging and has a good seal.
5. Examine the furnace casing for obvious signs of deterioration.
6. Examine the burner flames to make sure they are in good adjustment. Refer to the pictorial sketch shown in Figure 2 as a comparison to the actual flame.



FIGURE 2: Burner Flame Drawing


EXAMINE EXTERNAL VENT PIPE
5 EXAMINE ENTIRE FURNACE CASING SHOWN IN ALL DRAWINGS
1 EXTERNAL HEAT EXCHANGER INTERNAL VENT COMBUSTION AIR PIPE. MUST REMOVE PANEL TO EXAMINE.
6 REMOVE PANEL TO EXAMINE BURNER FLAMES
4 EXAMINE FURNACE CASING
BURNER DOOR
BLOWER DOOR
4 EXAMINE FURNACE CASING
6 REMOVE PANEL TO EXAMINE BURNER FLAMES
3 EXAMINE RETURN AIR DUCT CONNECTION
3 EXAMINE RETURN AIR DUCT CONNECTION (side or bottom)

FIGURE 3: Furnace Examination Checkpoints

HOW YOUR GAS FURNACE WORKS

Your furnace is a very easy appliance to take for granted. Season after season, it sits there in your home, keeping you warm and comfortable. For this reason, you may never have given much thought to the way your furnace operates. In order to get the safest and most efficient operation from your furnace, you should understand how your furnace does its job.

When you set your thermostat to provide more heat in your home, you are starting the heating cycle of the furnace. First, the inducer motor starts to purge the heat exchanger of any remaining gases. Next, the hot surface ignitor glows and after a warm-up period the gas valve opens and ignition occurs. A short time later, the blower starts and distributes the warm air throughout the home. When the temperature setting on your thermostat is reached, the gas valve closes, the main burners are turned off, and the blower continues to run until the remaining warm air in the system is distributed. When the blower stops, the heating cycle has ended.

START-UP AND SHUTDOWN INSTRUCTIONS

Read the Instructions Below Before Trying to Start the Furnace

⚠WARNING

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, and/or loss of life.

A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.

B. BEFORE OPERATING; smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

C. Use only your hand to push the gas control switch to the “on” position. Never use tools. If the switch will not operate by hand, don’t try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.

D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control, which has been under water.

Operating Instructions:

1. STOP! Read the safety information above.
2. Set the thermostat to the lowest setting.
3. Turn off all electric power to the appliance.
4. Remove burner door.
5. Move gas control switch to the “OFF” position. Do not force. See Figure 4.
6. Wait five (5) minutes to clear out any gas. If you then smell gas, STOP! Follow “B” in the safety information above. If you don’t smell gas, go to next step.
7. Move gas control switch to the “ON” position. Do not force. See Figure 4.
8. Replace burner door.
9. Turn on all electric power to the appliance.
10. Set thermostat to the desired setting. Burner will light, which may take 30-60 seconds.
11. After three (3) trials for ignition, if the appliance will not operate follow the instructions, “TO TURN OFF THE APPLIANCE” and call your service technician or gas supplier.

To Turn Off the Appliance:

1. Set the thermostat to lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. Remove burner access panel.
4. Move gas control switch to the “OFF” position. See Figure 4.
5. Replace burner door.

⚠WARNING

Should overheating occur, or the gas valve fail to shut off, turn the external manual gas valve in the gas supply line to the furnace to the “off” position and let the furnace cool off before shutting off the electrical power supply. Refer to Figure 5 or 6.



FIGURE 4: Gas Valve


EXTERNAL MANUAL SHUTOFF VALVE
TO GAS SUPPLY
TO GAS SUPPLY
DRIP LEG
GROUNDED JOINT UNION MAY BE INSTALLED INSIDE OR OUTSIDE UNIT.

FIGURE 5: Upflow Gas Piping



FIGURE 6: Horizontal Gas Piping

NOTE: The spring-loaded safety cut-off switch, mounted under the blower deck will automatically cut off the electrical power supply to the furnace when the blower panel is removed. As a safety precaution, all electrical power and the gas supply to the furnace should be turned off before servicing.

FURNACE USER MAINTENANCE

⚠WARNING

Before proceeding, be sure the area is well ventilated. Turn the thermostat OFF. If the blower is running, wait until it stops automatically. Turn OFF the gas and electrical power supplies to the furnace. Check all metal parts and surfaces to be sure they have cooled to room temperature before you begin.

Every time the filters are changed the following items should be visually inspected:

- Check vent pipe for blockage or leakage.
- Check all components to be sure they are in good condition and that there are no obvious signs of deterioration.
- Check for dirt or lint on any surfaces or on components. Do not try to clean any of the surfaces or components. Cleaning of the furnace and its components must be done by a qualified service professional.

If, during the inspection of your furnace, you find any of the following conditions:

- Excessive amounts of dust and lint on components.
- Damaged or deteriorated components or surfaces.
- Leaks or blockage in the vent pipe passages.
- Water on any surface inside or outside of the furnace.

Do not operate the furnace, call a certified dealer / servicing contractor to check and / or clean your furnace, or for more information if you have questions about the operation of your furnace.

If all components appear to be in good operating condition, replace the front panels. Turn ON the gas and electrical power supplies to the furnace, and set thermostat to the desired temperature.

Air Filters

Dirty filters greatly restrict the flow of air and may cause damage to the moving parts of the furnace. If the filters become clogged the heat exchangers and blower motor could overheat resulting in a potentially dangerous situation.The filters should be checked every 3 months. On new construction, check the filters every week for the first four weeks and every three weeks after that, especially if the indoor fan is running continuously. When replacing the filter(s) you must use filters that are the same size as those recommended in Table 1. use the following procedure to determine the filter size. Never operate your furnace without a suitable air filter.

Removing Filters

Externally Mounted Air Filters

Some installations may have the air filter in a rack attached to the casing of the furnace or placed in the return air duct. You can gain access to the filter by pulling on the door or unscrewing the retaining screw, then slide the filter(s) out of its channel. Replace throw away filter(s) with the same size new filter(s). Throw away filter(s) may be replaced with cleanable filter(s) at this time. Cleanable filter(s) may be cleaned as described in the manufacturer instructions or as described below and then re-installed.

To replace the filter after cleaning you must do the following:

1. Slide filter into place.
2. Snap the door on or place the door in position and tighten the retaining screws, if provided.
3. Make sure the door is secure to the end of the filter rack.

TABLE 1: Filter Sizes

Cabinet Size	Side (in)	Side (cm)	Bottom (in)	Bottom (cm)
A	16 x 25	4.06 x 6.35	14 x 25	3.56 x 6.35
B	16 x 25	4.06 x 6.35	16 x 25	4.06 x 6.35
C	(2) 16 x 25	(2) 4.06 x 6.35	20 x 25	5.08 x 6.35

How to Clean your Filter

High-velocity filters may be cleaned with a vacuum cleaner or washed with a garden hose. Be sure to shake off excess water and allow filter to completely dry before re-installing the filter.

Blower Care

Even with good filters properly in place, blower wheels and motors will become dust laden after long months of operation. The entire blower assembly should be inspected annually. If the motor and wheel are heavily coated with dust, they can be brushed and cleaned with a vacuum cleaner. If the blower cannot be properly cleaned without removing it from the furnace, then this service must be performed by a qualified service agency.

⚠WARNING

Make sure you DO NOT move the clip on weight on the indoor fan wheel when cleaning the wheel. This weight is used to balance the wheel. Moving the weight will cause the fan wheel to vibrate.

Motor Lubrication

The motors in these furnaces are permanently lubricated, and do not require periodic oiling.

SECTION II: SERVICE AND MAINTENANCE MANUAL

SAFETY SECTION

The following safety rules must be followed when servicing the furnace.

⚠WARNING

ELECTRIC SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in dangerous operation, serious injury, death or property damage.

Improper servicing could result in dangerous operation, serious injury, and death or property damage.

- Before servicing, disconnect all electrical power to the furnace.
- When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.
- Verify proper operation after servicing.

FURNACE MAINTENANCE SECTION

The furnace should be cleaned and adjusted by a certified dealer or qualified service contractor once a year or before the start of every heating season. The following items must be cleaned and serviced or replaced if there are signs of deterioration.

1. The vent terminal screen (if applicable).
2. The furnace vent and combustion air intake passageways. Should it be necessary to service the vent/air intake system, the manufacturer recommends this service be conducted by a qualified service agency. The operation of this appliance requires the reassembly and resealing of the vent/air intake system.
3. The furnace burners, ignitor and flame sensor.

FURNACE CLEANING SECTION

NOTE: The cleaning operations listed below must be performed only by a qualified service agency.

Burner Removal/Cleaning

The main burners should be checked periodically for dirt accumulation. If cleaning is required, follow this procedure:

1. Turn off the electrical power to the unit.
2. Turn off the gas supply at the external manual shut-off valve and loosen the ground union joint.
3. Remove the upper access panel and remove the burner box cover.
4. Disconnect wires from flame sensor, rollout switch and HSI igniter. Remove igniter carefully, as it is easily broken.
5. Remove the screws that hold the burner box assembly to the vest panel and remove the assembly.
6. Remove burners from the burner assembly.
7. Burners may be cleaned by rinsing in hot water.
8. Reassemble the burners in the reverse order.

Cleaning the Heat Exchanger

Lower Heat Exchanger Access

1. Turn off the electrical power to the unit and turn off gas supply at the shutoff valve.
2. Remove the blower and burner compartment access doors. Disconnect the gas supply piping at the union to permit removal of the entire burner and gas control assembly from the vestibule panel. Use the wrench boss on the gas valve when removing or installing this piping. See Figure 4.
3. Unplug the igniter from the wire harness. Disconnect sensor and rollout switch wires located on top of the air shield. Identify and note the location of all leads for ease of reinstallation. Also disconnect the wires at the side rollout switches (upflow only) and the gas valve wires.
4. Remove the screws holding the burner assembly to the vestibule panel and remove this assembly. Handle the assembly carefully since it contains the igniter, which is fragile and easily broken. The lower portion of the heat exchanger will now be exposed. To clean the burner assembly, use a vacuum cleaner, or remove the burners as outlined in burner cleaning, and clean in hot water.

Upper Heat Exchanger Access

1. Perform steps 1-4 above.
2. Disconnect vent piping from the vent motor assembly at the top panel on the furnace (upflow only). On downflow models, the vent pipe is attached to the vent motor outlet. Remove this screw before proceeding.
3. Unplug the vent motor wires and ground wire. Remove the pressure switch tubing at the tap on the vent motor housing.

NOTE: It is recommended that replacement gaskets be available before removing vent motor.

4. Remove six mounting screws that hold the vent motor to the restrictor plate. The surface is gasketed and gasket can be reused if it is carefully removed. It is necessary to remove this assembly to gain access to the restrictor plate mounting holes. The assembly may be vacuumed if cleaning is necessary. If any vent assembly parts are damaged, replace with an entire new assembly (except for gaskets).
5. Remove the perimeter screws attaching the restrictor plate assembly to the vestibule panel. The surface is also gasketed. The assembly, including the flue baffle plate (rear) may be vacuumed or cleaned with hot water if necessary.
6. The upper portion of the heat exchanger is now accessible. With a long flexible wire brush, clean inside each tube at both the top and bottom. The brush must pass around the rear heat exchanger tubes. Vacuum loose scale and dirt from each tube.
7. Clean - Replace all components in reverse order. Re-gasket all surfaces which required a gasket. Reconnect all wiring. Reattach vent pipe and gas supply lines before restoring service to furnace. Restore electrical power, check gas supply piping for leaks, and then verify furnace operation.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

SEQUENCE OF OPERATION

The following describes the sequence of operation of the furnace. Refer to Figure 1 for component location.

1. Call for 1st stage only
   - On a call for 1st stage heat, the thermostat closes a circuit between R and W1.
   - The Microprocessor in the Furnace Control runs a ‘Self Check’.
   - The Control checks the Primary Limit, Auxiliary Limit, and Rollout Switches for closed contacts.
   - The Control checks that the Low Fire Pressure Switch (1LP) is open.
   - The Inducer Motor is energized on high speed, closing the contacts of 1LP.
   - The Control checks that 1LP is closed.
   - The Igniter is energized for 17 seconds.
   - The Gas Valve is energized on 1st Stage (Low Fire).
   - Flame Rectification is recognized within 7 seconds.
   - The Inducer is switched to low speed.
   - 30 seconds after flame is proven, the ‘Heat Low’ relay is energized providing 120 Volts AC to the Blower Motor.
   - At the same time, the EAC and Hum relays are energized, providing 120 Volts AC to the EAC Hot and Hum terminals.
2. Call for 2nd Stage after 1st Stage is operating
   - A call for 2nd Stage can be made by a 2-Stage thermostat, or by the W2 delay timer on the furnace control.
   - The Inducer Motor is shifted to high speed by the control, closing the contacts of 2LP (The High Fire Pressure Switch.).
   - The Control checks that 2LP is closed.
   - The Gas Valve is energized on 2nd Stage (High Fire).
   - The Control simultaneously de-energizes the Heat Low relay and energizes the Heat High relay, providing 120 Volts AC to a different speed of the Blower Motor.

3. 2nd Stage is satisfied, 1st Stage still calling.
   - If a Single Stage Thermostat is used, the Furnace will stay on High Fire until the thermostat is satisfied.
   - When the circuit between R and W2 is opened, the Control switches the Inducer Motor to low speed, causing the contacts of 2LP to open.
   - When 2LP opens, 2nd Stage of the Gas Valve is de-energized.
   - 30 seconds later, the Control switches the Blower from Heat High to Heat Low.
4. 1st Stage Satisfied
   - The Thermostat opens the circuit between R and W1
   - Immediately the Gas Valve is de-energized and Flame Rectification is lost.
   - The Inducer Motor is de-energized after a 15 second Post Purge and the Hum terminal is de-energized.
   - The 'Fan Off Delay' circuit is initiated. The Delay time can be field set at 60, 90, 120, or 180 seconds. It comes from the factory set at 60 seconds.
   - The Heat Low terminal is de-energized; stopping the Blower and the EAC terminal is de-energized.
5. 1st and 2nd Stage called simultaneously
   - The 1st stage call is processed as described in paragraph 1 above.
   - Once Flame Rectification is established, 2nd Stage is entered immediately as described in paragraph 2 above.
6. 1st and 2nd Stage satisfied simultaneously
   - Both stages of the Gas Valve are de-energized.
   - Flame Rectification is lost.
   - The Inducer and Hum relays are de-energized after a 15-second post purge.
   - 30 seconds later the Control shifts the Blower from Heat High to Heat Low.
   - After the Blower-Off Delay Circuit is satisfied, the Blower and EAC are de-energized.
7. Manual Fan Operation
   - With the thermostat in the Fan On position, a circuit is completed between R and G of the Control.
   - The Heat Low and EAC relays are energized by the Control.
8. Call for Cooling
   - The thermostat closes two circuits R to Y/Y2 and R to G. Since the Outdoor Unit is connected to Y and C at the Control, it is energized.
   - The Cool and EAC relays are energized by the Control.
   - A Blower-Off Delay Timing Circuit is energized by the call on Y.
9. Cooling call satisfied
   - The thermostat opens the R to Y/Y2 and R to G circuits.
   - The Outdoor Unit is de-energized.
   - The 60-second, Blower-Off Delay, timing circuit is initiated.
   - After 60 seconds, the Cool and EAC relays are de-energized.
10. Two-stage cooling. This furnace is equipped to handle a two-stage AC unit.
    - The wall thermostat will energize the Y1 circuit for low cooling and the Y2 circuit for high cooling.

CONTROL BOARD

Variable speed motors will adjust the motor speed in order to maintain the indoor fan CFM. The control board is used to control the blower speed thus the CFM when the unit is operating in the heating or cooling modes. The blower CFM for cooling can be modified by changing the jumper pin position on the taps selection marked COOL and ADJ.

The blower CFM for heating can be modified by changing the jumper pin position on the taps selection marked HEAT. The taps selection pins have been preset at the factory to provide the maximum CFM. "Air Flow Data" table in the installation manual list the recommended jumper pin settings.

If a lesser CFM is required for a specific HVAC system the taps selection pins can be moved to the "B", "C", or "D" positions. Pin "A" will provide the highest CFM and "D" will provide the lowest CFM. The taps selection marked DELAY are used for cooling only. The recommended settings for these jumper pins are listed in Delay taps selection.

HEATING AIRFLOW

The heating airflow has been preset at the factory to provide maximum CFM. If a lesser CFM is required for a specific HVAC system the "JUMPER" on the HEAT selection pins on the CFM-Timer Board may be moved to **tap "B", "C", or "D".**

HEAT Taps Selection on the control board

Pin Position A: will provide the highest CFM.

Pin Position B and C: are the medium and medium low CFM settings.

Pin Position D: will provide the lowest CFM.

Refer to "Air Flow Data" table in the installation manual for the proper "HEAT" Taps Selection for the model furnace you are installing.

NOTE: When changing jumper positions, make sure that the jumper is pushed all the way on the pins. If the jumper is not making good contact or is left off completely, the blower will operate as if the jumper were in the "**A" position**.

NOTE: Power to the blower must be removed for at least 4 seconds after a heat or cool tap selection change, in order for the motor to recognize an adjustment. The fixed blower on delay and adjustable blower-off delay will function as described in the "OPERATION AND MAINTENANCE" Section in the Users Information Manual.

ADJUSTMENT OF FAN CONTROL SETTINGS

Heating Indoor Fan Off Delay

Changing the blower delay jumper on the Furnace Control Board can change the indoor fan "OFF" time delay. Refer to Figure 7 for the jumper settings to obtain the desired fan OFF delay. The blower off delay must be long enough to adequately cool the furnace, but not so long that cold air is blown into the living space.

The blower on delay is fixed at 30 seconds and cannot be adjusted.



FIGURE 7: Furnace Control Board

Continuous Blower Operation:

The blower will run continuously whenever the wall thermostat fan switch is in the "ON" position. The furnace blower will run at the speed selected on the "FAN SPEED" jumpers on the main control board (HI COOL, LO COOL, HI HEAT or LO HEAT). When the jumper is in the "VS G" position, the blower will run at 50% of the high cool speed.

Delay Tap Selection

The set of jumper pins on the control board labeled "DELAY" are used to set the delay profiles for the furnace. These can be chosen so as to maximize the comfort and sound levels for various regions of the country.

Tap A is the default profile. It provides a 15-second ramp-up from zero airflow to full capacity and a 15-second ramp-down from full capacity back to zero airflow. Whenever there is a change in airflow mode, such as from low heat to high heat, the motor will take 15 seconds to ramp from one speed to the other.

Tap B is the humid profile. This profile is best-suited for installations where the humidity is frequently very high during cooling season, such as in the southern part of the country. On a call for cooling, the blower will ramp up to 50% of full capacity and will stay there for two minutes, then will ramp up to 82% of full capacity and will stay there for five minutes, and then will ramp up to full capacity, where it will stay until the wall thermostat is satisfied. In every case, it will take the motor 15 seconds to ramp from one speed to another.

Tap C is the dry profile. This profile is best suited to parts of the country where excessive humidity is not generally a problem, where the summer months are usually dry. On a call for cooling the motor will ramp up to full capacity and will stay there until the thermostat is satisfied. At the end of the cooling cycle, the blower will ramp down to 50% of full capacity where it will stay for 60 seconds. Then it will ramp down to zero. Any ramp up to a higher speed will take 30 seconds and any ramp down to a lower speed (or off) will take 60 seconds.

Tap D is the normal profile, best suited for most of the country, where neither excessive humidity nor extremely dry conditions are the norm. On a call for cooling, the motor will ramp up to 63% of full capacity and will stay there for 90 seconds, then will ramp up to full capacity. At the end of the cooling cycle, the motor will ramp down to 63% of full capacity and will stay there for 30 seconds, then will ramp down to zero. In every case, it will take the motor 15 seconds to ramp from one speed to another.

Humidistat

When a humidistat is installed in the system, the “Humidistat Installed?” jumper on the control board should be moved to the “YES” position. The cooling CFM will then be reduced by 15% whenever the humidistat indicates high humidity.

Hot Surface Ignition System

⚠WARNING

HOT SURFACE IGNITION SYSTEM

Do not attempt to light this furnace by hand (with a match or any other means). There may be a potential shock hazard from the components of the hot surface ignition system. The furnace can only be lit automatically by its hot surface ignition system.

TROUBLESHOOTING

The following visual checks should be made before troubleshooting:

1. Check to see that the power to the furnace and the ignition control module is ON.
2. The manual shut-off valves in the gas line to the furnace must be open.
3. Make sure all wiring connections are secure.
4. Review the sequence of operation. Start the system by setting the thermostat above the room temperature. Observe the system’s response. Then use the troubleshooting section in this manual to check the system’s operation.

⚠WARNING

Never bypass any safety control to allow furnace operation. To do so will allow furnace to operate under potentially hazardous conditions.

Do not try to repair controls. Replace defective controls with UPG Source 1 Parts.

Never adjust pressure switch to allow furnace operation.

FURNACE CONTROL DIAGNOSTICS

The furnace has built-in, self-diagnostic capability. If a system problem occurs, a blinking LED shows a fault code. The LED can flash red, green or amber to indicate various conditions. It is located behind a clear view port in the blower compartment door.

The control continuously monitors its own operation and the operation of the system. If a failure occurs, the LED will indicate the failure code. If the failure is internal to the control, the light will stay on continuously. In this case, the entire control should be replaced, as the control is not field repairable.

Flash sequence codes 1 through 10 are as follows: LED will turn “on” for 1/4 second and “off” for 1/4 second. This pattern will be repeated the number of times equal to the code. For example, six “on” flashes equals a number 6 fault code. All flash code sequences are broken by a 2 second “off” period.

SLOW GREEN FLASH: Normal operation.

SLOW AMBER FLASH: Normal operation with call for heat.

RAPID RED FLASH: Twinning error, incorrect 24V phasing. Check twinning wiring.

RAPID AMBER FLASH: Flame sense current is below 1.5 microamps. Check and clean flame sensor. Check for proper gas flow.

4 AMBER FLASHES: The control board is recieving a “Y” signal from the thermostat without a “G” signal, indicating improper thermostat wiring.

1 RED FLASH: This indicates that flame was sensed when there was not a call for heat. With this fault code the control will turn on both the inducer motor and supply air blower. A gas valve that leaks through or is slow closing would typically cause this fault.

2 RED FLASHES: This indicates that the normally open pressure switch contacts are stuck in the closed position. The control confirms these contacts are open at the beginning of each heat cycle. This would indicate a faulty pressure switch or miswiring.

3 RED FLASHES: This indicates the normally open pressure switch contact did not close after the inducer was energized. This could be caused by a number of problems: faulty inducer, blocked vent pipe, broken pressure switch hose or faulty pressure switch.

4 RED FLASHES: This indicates that a primary or auxiliary limit switch has opened its normally closed contacts. With this fault code the control will operate the supply air blower and inducer. This condition may be caused by: dirty filter, improperly sized duct system, incorrect blower speed setting, incorrect firing rate or faulty blower motor.

5 RED FLASHES: This fault is indicated if the normally closed contacts in the rollout switch opens. The rollout control is manually reset. If it has opened, check for proper combustion air, proper inducer operation, and primary heat exchanger failure or burner problem. Be sure to reset the switch after correcting the failure condition.

6 RED FLASHES: This indicates that after the unit was operating, the pressure switch opened 4 times during the call for heat. If the main blower is in a “Delay on” mode it will complete it, and any subsequent delay off period. The furnace will lock out for one hour and then restart.

7 RED FLASHES: This fault code indicates that the flame could not be established. This no-light condition occurred 3 times (2 retries) during the call for heat before locking out. Low gas pressure, faulty gas valve, faulty hot surface ignitor or burner problem may cause this. The furnace will lock out for one hour and then restart.

8 RED FLASHES: This fault is indicated if the flame is lost 5 times (4 recycles) during the heating cycle. This could be caused by low gas pressure or faulty gas valve. The furnace will lock out for one hour and then restart.

9 RED FLASHES: Indicates reversed line voltage polarity or grounding problem. Both heating and cooling operations will be affected. Check polarity at furnace and branch. Check furnace grounding. Check that flame probe is not shorted to chassis.

10 RED FLASHES: Gas valve energized with no call for heat. Check gas valve and gas valve wiring.

11 RED FLASHES: This indicates that a primary or auxiliary limit switch has opened its normally-closed contacts and has remained open for more than five minutes. This condition is usually caused by a failed blower motor or blower wheel.

12 RED FLASHES: This code indicates an open igniter circuit, which could be caused by a disconnected or loose wire or by a cracked or broken igniter.

STEADY ON RED: Control failure. Replace control board.

60-MINUTE AUTOMATIC RESET FROM LOCKOUT: This control includes a “watchdog” type circuit that will reset from a lockout condition after 60 minutes. Operational faults 6,7,8 will be reset. This provides protection to an unoccupied structure if a temporary condition exists causing a furnace malfunction. An example would be a low incoming gas supply pressure preventing unit operation. When the gas pressure is restored, at some point the “watchdog” would restart the unit and provide heat for the house.

NOTE: If a flame is detected the control flashes the LED for 1/8 of a second and then enters a flame stabilization period.

IGNITION CONTROL
Normal flame sense current is approximately
3.7 microamps DC (µa)
Low flame signal warning starts at 1.5 microamps.
Low flame signal control lockout point is
0.1 microamps DC (µa)

DIAGNOSTIC FAULT CODE STORAGE AND RETRIEVAL

The control in this furnace is equipped with memory that will store up to five error codes to allow a service technician to diagnose problems more easily. This memory will be retained even if power to the furnace is lost. **This feature should only be used by a qualified service technician.**

The control stores up to five separate error codes. If more than five error codes have occurred since the last reset, only the five most recent will be retained. The furnace control board has a button, labeled "LAST ERROR" that is used to retrieve error codes. This function will only work if there are no active thermostat signals. So any call for heating, cooling or continuous fan must be terminated before attempting to retrieve error codes.

To retrieve the error codes, push the LAST ERROR button. The LED on the control will then flash the error codes that are in memory, starting with the most recent. There will be a two-second pause between each flash code. After the error codes have all been displayed, the LED will resume the normal slow green flash after a five second pause. To repeat the series of error codes, push the button again.

If there are no error codes in memory, the LED will flash two green flashes. To clear the memory, push the LAST ERROR button and hold it for more than five seconds. The LED will flash three green flashes when the memory has been cleared, then will resume the normal slow green flash after a five-second pause.



NOTE:
1. THIS DIAGRAM SHOWS TWO IGNITION ATTEMPTS
2. TIMING LENGTHS ARE NOT TO SCALE

FIGURE 8: Furnace Control Event Schedule

SECTION III: REPLACEMENT PARTS LIST





ITEM	DESCRIPTION
MOTOR	
1	MOTOR/MODULE COMPLETE (Programmed
1A	ECM PROGRAMMED MODULE (Less Motor)
1B	MOTOR, BLOWER (MOTOR ONLY, LESS ECM MODULE)
2	MOTOR, VENTOR ASS'Y
ELECTRICAL	
3	CHOKE, PSC
4	CONTROL, HIGH LIMIT
5	CONTROL, FURNACE [FC]
6	IGNITER
7	SENSOR, FLAME
8	SWITCH, AIR PRESSURE [1LP]
9	SWITCH, DOOR [SW]
10	TRANSFORMER
11	VALVE, GAS
12	SWITCH, FLAME ROLL-OUT [ROS 3]
12A	SWITCH, FLAME ROLL-OUT (2 ea.)[ROS1,2]
13	
14	FUSE (ARO 3)
15	
AIR MOVING	
16	HOUSING, BLOWER
16A	WRAP, FILLER PANEL
17	WHEEL, BLOWER
FABRICATED PARTS	
18	
19	BAFFLE, FLUE
20	BURNER, MAIN GAS
21	BRACKET, IGNITER
22	DECK, BLOWER (Rear)
23	DECK, FRONT
24	HEAT EXCHANGER ASS'Y
25	MANIFOLD, GAS
26	PANEL, UPPER ACCESS (Burner) (Magnet)

ITEM	DESCRIPTION
FABRICATED PARTS (Continued)	
27	PAN, BASE
28	PANEL, BLOWER ACCESS (Magnet)
29	PANEL, TOP
30	WRAPPER, INSULATED
31	CHANNEL, TOE PLATE
32	
33	
34	
35	FRAME, SIDE BASE (2 Req'd)
36	BRACKET, ROLL-OUT SWITCH
37	ORIFICE, BURNER (Natural #45)
38	PLATE, RESTRICTOR
39	COLLAR, FLUE
40	LO-NOX SCREEN ("L" Models Only)
MISCELLANEOUS	
41	
42	SIGHT GLASS, OVAL
43	GASKET, RESTRICTOR PLATE
44	TUBING, SILICONE
45	
46	DIAGRAM, WIRING
47	HARNESS, MAIN WIRING
48	FERRULE (3 Req'd)
49	GROMMET (3 Req'd)
50	
51	MOUNT, MOTOR
52	GROMMET, 1/2" DIA.
53	KNOB, DOOR (4 Req'd) (Magnet)
54	HARNESS, MOTOR WIRING (16 Pin)
55	
56	MAGNET, DOOR

NOTE: *Not Shown

Major components and suggested stocking items are shown with shaded item number.

TABLE 2: Field Installed Accessories - Non Electrical

MODEL NO.	DESCRIPTION	USED WITH
1NP0347	PROPANE (LP) CONVERSION KIT	ALL MODELS
1PS0313	HIGH ALTITUDE PRESSURE SWITCH KIT (DOES NOT INCLUDE ORIFICES)	57, 80, 100 MBH
1PS0314		120 MBH
1SR0302	SIDE RETURN FILTER KIT 1” FILTER	ALL MODELS
1SR0200	SIDE RETURN FILTER KIT 1-4” FILTER	ALL MODELS
1BR0114	BOTTOM RETURN FILTER KIT 1” FILTER	14-1/2” CABINETS
1BR0214	BOTTOM RETURN FILTER KIT 1-4” FILTER	14-1/2” CABINETS
1BR0117	BOTTOM RETURN FILTER KIT 1” FILTER	17-1/2” CABINETS
1BR0217	BOTTOM RETURN FILTER KIT 1-4” FILTER	17-1/2” CABINETS
1BR0121	BOTTOM RETURN FILTER KIT 1” FILTER	21” CABINETS
1BR0221	BOTTOM RETURN FILTER KIT 1-4” FILTER	21” CABINETS
1BR0124	BOTTOM RETURN FILTER KIT 1” FILTER	24-1/2” CABINETS
1BR0224	BOTTOM RETURN FILTER KIT 1-4” FILTER	24-1/2” CABINETS
1HF0801	INTERNAL FILTER KIT WITH 1” FIBER FILTER	ALL MODELS

REPLACEMENT PART CONTACT INFORMATION

This is a generic parts list. To request a complete parts list, refer to the contact information below:

- Visit our website at www.source1parts.com for the following information:
  1. Search for a part or browse the catalog.
  2. Find a dealer or distributor.
  3. Customer Service contact information.
     a. Click on the “Brand Links” button
     b. Click on the “Customer Service” button
- You can contact us by mail. Just send a written request to:

York International
Consumer Relations
5005 York Drive
Norman, OK 73069

SECTION IV: WIRING DIAGRAM


LADDER DIAGRAM
DIAGRAMME ELEMENTAIRE
80% TWO-STAGE VARIABLE SPEED FURNACE
(FOURNAISE 80% À 2 STAGES VENTILÉE PAR ET A VITESSE VARIABLE)
- CAUTION -
OPEN ALL DISCONNECTS BEFORE SERVICING THIS UNIT
- PRÉCAUTION -
OUVREZ LES DISJONCTEURS AVANT DE PROCÉDER AVEC LE SERVICE
WIRE COLOR KEY
(CODE DE COULEUR DU FILAGE)
BLK BLACK (NOIR)
BLU BLUE (BLEU)
RED RED (ROUGE)
YEL YELLOW (JAUNE)
WHT WHITE (BLANC)
BRN BROWN (BRUN)
GRN GREEN (VERT)
PRP PURPLE (POURPRE)
ORN ORANGE (ORANGE)
LEGEND
DS DISCONNECT SWITCH
GV GAS VALVE
IGN HOT SURFACE IGNITOR
P1/S1 5 PIN PLUG & SOCKET ON FURNACE CONTROL BOARD
P2/S2 5 PIN PLUG & SOCKET ON FURNACE CONTROL BOARD
P3/S3 2 PIN PLUG & SOCKET AT HOT SURFACE IGNITOR
P4/S4 4 PIN PLUG & SOCKET ON BLOWER MOTOR
P5/S5 3 PIN PLUG & SOCKET ON VALVE
P6/S6 16 PIN PLUG & SOCKET FOR MOTOR
P9/S9 9 PIN PLUG & SOCKET ON BLOWER MOTOR
P8/S8 16 PIN PLUG & SOCKET ON FURNACE CONTROL BOARD
LS1 PRIMARY LIMIT SWITCH
ROS1 ROLL OUT SWITCH LEFT SIDE
ROS2 ROLL OUT SWITCH CENTER SIDE
ROS3 ROLL OUT SWITCH TOP SIDE (2-5 CELL)
ROS4 ROLL OUT SWITCH TOP RIGHT (5 & 7 CELL)
OR
ROS4 ROLL OUT SWITCH TOP LEFT (6 & 7 CELL ONLY)
FUSE
ILP PRESSURE SWITCH, FIRST STAGE
2LP PRESSURE SWITCH, SECOND STAGE
PF FUSE, 3 AMP, 250V
24V CONNECTION FROM THERMOSTAT
FIELD CONNECTION
FACTORY WIRING AND DEVICES
FIELD WIRING AND DEVICES
RELAY CONTACTS ON FURNACE CONTROL BOARD
PF POWER FACTOR TRANSFORMER
LÉGENDE
DS COMMUTATEUR DE DISJONCTION
GV SOUPAPE DE GAZ
IGN IGNITION DE SURFACE CHAUDE
P1/S1 PRISE ET RECEPTACLE À 5 PTS SUR LA PLAQUETTE DE CONTRÔLE D'IGNITION
P2/S2 PRISE ET RECEPTACLE À 5 PTS SUR LA PLAQUETTE DE CONTRÔLE D'IGNITION
P3/S3 PRISE ET RECEPTACLE À 2 PTS D'IGNITION DE SURFACE CHAUDE
P4/S4 PRISE ET DOUILLE À 4 PATTES SUR LE MOTEUR SOUFFLERIE
P5/S5 PRISE ET DOUILLE À 3 PATTES SUR LA SOUPAPE
P6/S6 PRISE ET RECEPTACLE À 16 PTS POUR LE MOTEUR DE LA SOUFFLERIE
P9/S9 PRISE ET RECEPTACLE À 9 PTS POUR LE MOTEUR DE LA SOUFFLERIE
P8/S8 PRISE ET DOUILLE À 16 PATTES SUR LA PLAQUETTE DE CONTRÔLE D'IGNITION
LS1 COMMUTATEUR DE LIMITE PRINCIPALE
ROS1 COMMUTATEUR DE ROULEMENT - CÔTÉ GAUCHE
ROS2 COMMUTATEUR DE ROULEMENT - HAUT CENTRE
ROS3 COMMUTATEUR DE ROULEMENT - HAUT DROIT (5 & 7 CELL)
ROS4 COMMUTATEUR DE ROULEMENT - 1SEULEMENT 6 & 7 CELL)
FUSIBLE
ILP PREMIER STAGE DU COMMUTATEUR DE PRESSION
2LP DEUXIÈME STAGE DU COMMUTATEUR DE PRESSION
PF TRANSFORMATEUR 40VA
24V RACCORDEMENT DU THERMOSTAT DE PIECE
RACCORDEMENT DE CHANTIER
FILAGE DE L'USINE ET APPAREILS
FILAGE DE CHANTIER ET APPAREILS
CONTACTES DES RELAIS SUR LA PLAQUETTE DE CONTRÔLE D'IGNITION
PF TRANSFORMATEUR DU FACTEUR DE PUISSANCE
CONNECTION DIAGRAM
(DIAGRAMME DE RACCORDEMENT)
NOTES:
1. ALL FIELD WIRING PER: (A) NATIONAL ELEC. CODE (NEC) AND/OR/
(B) CANADIAN ELEC. CODE (CEC) AND/OR/
(C) LOCAL OR CITY CODES
2. IF ANY OF THE ORIGINAL WIRE AS SUPPLIED WITH THE FURNACE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 221F (105C).
3. CONNECTORS SUITABLE FOR COPPER CONDUCTORS ONLY.
4. ALL POWER SUPPLY CONDUCTORS MUST BE PROPERLY GROUNDED.
5. PROVIDE DISCONNECTS FOR ALL POWER SUPPLIES.
6. MOTORS ARE INHERENTLY PROTECTED.
7. REMOVE THE DELAY TIMER HARNESS WHEN USING A 2 STAGE THERMOSTAT.
8. TIMER JUMPER MUST BE IN OFF POSITION WHEN USING A TWO STAGE THERMOSTAT.
NOTES:
1. TOUT FILAGE EN CHANTIER SELON: (A) CODE ELEC. NATIONAL (CEN) ET/OU/
(B) CODE ELEC. CANADIEN (CEC) ET/OU/
(C) CODES LOCAL ET MUNICIPAL.
2. SI LE FILAGE DOIT ÊTRE REMPLACÉ EN PARTIE OU EN TOUT, IL DOIT L'ÊTRE AVEC UN MATÉRIAUX POUVANT RÉSISTER A DES TEMPÉRATURES D'AU MOINS 221°F (105°C).
3. SEULEMENT DES MARETTES POUR FIL DE CUIVRE.
4. TOUTE COMPOSANTE DE REMPLACEMENT DOIT ÊTRE BIEN MISE EN TERRE.
5. FOURNISSEZ LES DISJONCTEURS POUR L'ALIMENTATION.
6. LES MOTEURS SONT PROTE.GÉS DE PAR LEUR CONCEPTION.
7. ENLEVEZ LE HARNAIS DE LA MINUTERIE DE DELAI LORSQUE VOUS UTILISEZ UN THERMOSTAT A 2 STAGES.
8. LE CAVALIER DE LA MINUTERIE DOIT ÊTRE EN POSITION OFF LORSQUE VOUS UTILISEZ UN THERMOSTAT A DEUX STAGES.
270848-UWD-A-0107

FIGURE 9: Wiring Diagram

NOTES

NOTES

Limited Warranty

UPG warrants this product to be free from defects in factory workmanship and material under normal use and service and will, at its option, repair or replace any parts that prove to have such defects according to the terms outlined on this warranty. This warranty covers only the equipment described by the Product Model Number and Serial Number listed on the Warranty Registration Card.

UPG warrants the primary heat exchangers in the product to be free from defects in factory workmanship and material under normal use and service and will at its option, repair or furnish a replacement heat exchanger, either new or reconditioned, that meets the intended fit, use and function of the original heat exchanger for any heat exchanger furnished by UPG which proves to have such defects within the duration of warranty coverage. Alternatively, UPG may, at its option, extend a replacement allowance to be applied toward the purchase of a new furnace or packaged unit marketed by UPG. The exact amount of the allowance will be determined at the discretion of UPG, based upon current market conditions, but in no case shall this allowance exceed thirty (30) percent of the original consumer purchase price of the furnace, excluding such items as ductwork, wiring, piping and installation costs. UPG shall have no responsibility hereunder for installation, shipping, handling or other charges except as specifically provided herein.

For your benefit and protection, return the Warranty Registration Card to UPG promptly after installation. This will initiate the warranty period and allow us to contact you, should it become necessary. In the absence of a recorded Warranty Registration Card, the warranty period will begin upon product shipment from UPG.

This warranty extends only to the original consumer purchaser and is non-transferable. For this warranty to apply, the product must be installed according to UPG recommendations and specifications, and in accordance with all local, state, and national codes; and the product must not be removed from its place of original installation. The warranty period for repair or replacement parts provided hereunder shall not extend beyond the warranty period stated on the reverse side of this warranty.

FURNACE TYPE		HEAT EXCHANGER			PARTS
		Residential Applications		Non-Residential Applications	
		Original Owner	Subsequent Owner		
80%	PV8V / FC8V / FL8V / LC8V / LL8V	20	N/A	10	5

UPG strongly recommends regular periodic preventative maintenance on this equipment. The person most familiar with the equipment in your HVAC system is a UPG dealer. The UPG dealer can ensure your maintenance program meets the conditions of the "UPG Warranty", maximize the efficiency of the equipment, and service your unit within the mandated guidelines with regard to unlawful discharge of refrigerants into the atmosphere.

This warranty applies only to products installed in the United States and Canada.

EXCLUSIONS

This warranty does not cover any:

1. Shipping, labor, or material charges.
2. Damages resulting from transportation, installation, or servicing.
3. Damages resulting from accident, abuse, fire, flood, alteration, or acts of God (tampering, altering, defacing or removing the product serial number will serve to void this warranty).
4. Damages resulting from use of the product in a corrosive atmosphere.
5. Damages resulting from inadequacy or interruption of electrical service or fuel supply, improper voltage conditions, blown fuses, or other like damages.
6. Cleaning or replacement of filters.
7. Damages resulting from failure to properly and regularly clean air and/or water side of condenser and evaporator.
8. Damages resulting from: (I) freezing of condenser water or condensate; (II) inadequate or interrupted water supply; (III) use of corrosive water; (IV) fouling or restriction of the water circuit by foreign material or like causes.
9. Damages resulting from operation with inadequate supply of air or water.
10. Damages resulting from use of components or accessories not approved by UPG (vent dampers, etc.).
11. Increase in fuel or electric cost.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

SOME STATES DO NOT ALLOW THE DISCLAIMER OF IMPLIED WARRANTY, SO THAT THE ABOVE DISCLAIMER MAY NOT APPLY TO YOU.

SOME STATES ALLOW ONLY A PARTIAL LIMITATION ON IMPLIED WARRANTIES TO LIMIT THE DURATION OF IMPLIED WARRANTIES TO THE DURATION OF THE EXPRESS WARRANTY. IN SUCH STATES, THE DURATION OF IMPLIED WARRANTIES IS HEREBY EXPRESSLY LIMITED TO THE DURATION OF THE EXPRESS WARRANTY ON THE FACE HEREOF.

IN NO EVENT, WHETHER AS A RESULT OF BREACH OF WARRANTY OR CONTRACT, TORT (INCLUDING NEGLIGENCE) STRICT LIABILITY OR OTHERWISE, SHALL UPG BE LIABLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF USE OF THE EQUIPMENT OR ASSOCIATED EQUIPMENT, LOST REVENUES OR PROFITS, COST OF SUBSTITUTE EQUIPMENT OR COST OF FUEL OR ELECTRICITY. THE ABOVE LIMITATIONS SHALL INURE TO THE BENEFIT OF UPG'S SUPPLIERS AND SUBCONTRACTORS. THE ABOVE LIMITATION ON CONSEQUENTIAL DAMAGES SHALL NOT APPLY TO INJURIES TO PERSONS IN THE CASE OF CONSUMER GOODS.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, OR FOR STRICT LIABILITY IN TORT, SO THAT THE ABOVE EXCLUSIONS AND LIMITATIONS MAY NOT APPLY TO YOU.

UPG DOES NOT ASSUME, OR AUTHORIZE ANY OTHER PERSON TO ASSUME FOR UPG, ANY OTHER LIABILITY FOR THE SALE OF THIS PRODUCT.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

For Owner's Information:

PRODUCT MODEL. NO. _____ INSTALLATION DATE _____
UNIT SERIAL NO. _____ INSTALLING DEALER _____

Subject to change without notice. Printed in U.S.A.
271002-UUM-A-0407
Copyright © by York International Corp. 2007. All rights reserved.
Supersedes: 167188-UUM-B-0806

Unitary Products Group
5005 York Drive
Norman OK 73069